Panasonic

Installation Guide

Included Installation Instructions

Network Camera For professional use only Indoor use

roduct documentation is composed of the following documents.

perform the settings and how to operate this camera.

ttps://security.panasonic.com/training_support/docume

Installation Guide (this document): Provides information about "Precautions", "Precautions for installation" and the installation method.

Basic Information (in the following manual website): Provides information about "Precautions for use", "Parts and functions" and "Detail specifications".
Operating Instructions (in the following manual website): Explains how to

Model No. WV-S1136

About the user manuals

on our support website (https://security.panasonic.com/training_support/support/info/) and will guide you to the right information.

"<Control No.: C****>" used in these documents should be used to search for information

- Before attempting to connect or operate this product, please read these instructions carefully and save this manual for future use.
- microSDXC/ microSDHC/ microSD memory card is described as microSD memory card.
- The external appearance and other parts shown in this manual may differ from the actual product within the scope that will not interfere with normal use due to improvement of the product.

For Europe and other countries:

Panasonic Marketing Europe GmbH

Winsbergring 15, 22525 Hamburg, Germany

* PGQX2443YA* avs0221-1041/1 Printed in China

expressly approved by the party responsible for com-

pliance could void the user's authority to operate the

Supplier's Declaration of conformity

Support Contact : 1-800-528-6747

Panasonic Corporation of North America

Two Riverfront Plaza, Newark, New Jersey

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions

(1)This device may not cause harmful interference,

and (2) this device must accept any interference

received, including interference that may cause

Trade name : Panasonic

Model No. : WV-S1136

Responsible Party

07102-5490

-For U.S.A.

undesired operation.

Printed in China

Panasonic Corporation

http://www.panasonic.com

For U.S. and Canada:

Panasonic i-PRO Sensing Solutions Corporation of America 800 Gessner Rd, Suite 700 Houston, TX 77024 https://www.security.us.panasonic.com

Panasonic i-PRO Sensing Solutions Co., Ltd. Fukuoka, Japan Panasonic Canada Inc. 5770 Ambler Drive, Mississauga, Ontario, L4W 2T3 Canada Authorised Representative in EU: 1-877-495-0580 https://www.panasonic.com/ca/ Panasonic Testing Centre

© Panasonic i-PRO Sensing Solutions Co., Ltd. 2021

Disposal of Old Equipment and Batteries

- Only for European Union and countries with recycling systems
- These symbols on the products, packaging, and/or accompanying documents mean that used electrical and electronic products and batteries must not be mixed with general household waste.
- For proper treatment, recovery and recycling of old products and used batteries, please take them to applicable collection points in accordance with your national legislation. By disposing of them correctly, you will help to save valuable resources and prevent any potential
- negative effects on human health and the environment. For more information about collection and recycling, please contact your local authority.

equipment.

- Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation. Note for the battery symbol (bottom symbol)
- This symbol might be used in combination with a chemical symbol. In this case it complies with the requirement set by the Directive for the chemical involved.

For U.S.A.

NOTE: This equipment has been tested and found to FCC CAUTION: Changes or modifications not comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

- For U.S.A.

The model number and serial number of this product may be found on the surface of the unit. You should note the model number and serial number of this unit in the space provided and retain this book as a permanent record of your purchase to aid identification in the event of theft. Model No.



– For Canada -

CAN ICES-3(A)/NMB-3(A)		
Méthode d'installation	Vis de fixation recommandée	La capacité de traction minimale requise
Pour une installation au plafond Platine de fixation d'installation: 260 g {0,57 lbs} Caméra vidéo: 370 g {0,82 lbs}	M6 x 16 mm {5/8 pouces}/ 4 él.	562 N {126 lbf}
Pour une installation murale Platine de fixation d'installation: 420 g {0,93 lbs} Caméra vidéo: 370 g {0,82 lbs}	M6 x 16 mm {5/8 pouces}/ 4 él.	724 N {163 lbf}
Pour fixer le câble de sécurité	M4 x 16 mm {5/8 pouces}/ 1 él.	24.5 N {5.5 lbf}

* La longueur de la vis est un exemple lors de l'installation de la caméra au plafond

ou sur un mur robuste d'une épaisseur de 20 mm {25/32 pouces} ou plus.

Caution: be in the same building.

Micro

XC

- The network camera is only intended for a connection to an ethernet or PoE network without routing to the outside plant.
- This product has no power switch. Be sure to install disconnect devices such as a circuit breaker to shut down the main power of power supplying equipment to this product.
- Only connect 12 V DC Class 2 power supply (UL 1310/ CSA 223), limited power source (IEC/EN/UL/CSA 60950-1, IEC/EN/UL/CSA 62368-1 Annex Q) or IEC/EN/UL/CSA 62368-1

Turn the power off immediately and contact qualified service personnel for service.

produced.

■ Do not strike or give a strong shock to this product.

Failure to observe this may cause injury or fire.

Otherwise, they may swallow the cards by mistake.

■ Do not hang down from this product or use this product as a pedestal.

Do not damage, fabricate, twist, stretch, bundle, or forcibly bend the power cable. Do not place heavy objects on it,

Use of a damaged power cable may cause electric shock, short circuit, or fire.

■ Do not attempt to disassemble or modify this product.

Failure to observe this may cause fire or electric shock. Consult the dealer for the repair or inspections.

cables during thunder storms.

When smoke goes up from the product, the smell of smoke comes from the product, or the exterior of the product has deteriorated, continued use will cause a fire or fall of the product resulting in injury, or damage to the product. In this case, turn the power off immediately and contact qualified service personnel for service.

Select an installation area that can support the total weight.

Selecting an inappropriate installation surface may cause this product to fall down or topple over, resulting in injury or accidents. Installation work shall be started after sufficient reinforcement.

Periodic inspections shall be conducted.

Rust on the metal parts or screws may cause a fall of the product resulting in injury or accidents. Consult the dealer for the inspections.

Turn the power off when do wiring of this product.

Failure to observe this may cause electric shock. In addition, short circuit or wrong wiring may cause fire.

■ Install this product in a location high enough to avoid people and objects from bumping the product.

Failure to observe this may cause injury.

The measures of protection against a fall of this product shall be taken.

Failure to observe this may cause a drop resulting in injury.

Be sure to install the safety wire

Do not install this product in locations subject to vibration. Loosening of mounting screws or bolts may cause a fall of the product resulting in injury or accidents.

■ Correctly perform all wiring.

Short circuits in the wiring or incorrect wiring may cause fire or electrical shock. Install the product securely on a wall or a ceiling in accordance with the installation instructions

Failure to observe this may cause injury or accidents.

Do not rub the edges of metal parts with your hand.

Failure to observe this may cause injury

Turn the power off when cleaning this product. Failure to observe this may cause injury.

• The DC power supply connected to the camera must • This product is not suitable for use in locations where children are likely to be present.

- Do not install this product in locations where ordinary persons can easily reach.
- This product is a professional equipment. For information about screws and other parts required for installation, refer to the corresponding section of this document.

: Direct current symbol

 Before attempting to connect or operate this product, please read these instructions carefully.

Precautions

■ Do not insert any foreign objects.

Fire or electrical shock may be caused if water or any foreign objects, such as metal objects, enter inside the unit.

Notice:

■ Do not use this product in an inflammable atmosphere.

Failure to observe this may cause an explosion resulting in injury.

Avoid installing this product in the locations where salt damage occurs or corrosive gas is

Otherwise, the mounting portions will deteriorate and injury or accidents due to a fall of the product may occur.

■ Keep microSD memory cards away from infants and children.

In this case, consult a doctor immediately.

Failure to observe this may cause injury or accidents.

■ Do not damage the power cable.

and keep it away from heat sources.

Consult the dealer for repair.

■ Do not install or clean the camera, or touch this product, the power cable or the connected

Failure to observe this may cause electric shock.

Refer installation work to the dealer.

Installation work requires technique and experience. Failure to observe this may cause fire, electric shock, injury, or damage to the product. Be sure to consult the dealer

■ Stop the operation immediately when something is wrong with this product.

Open Source Software

• This product contains open source software licensed under GPL (GNU General Public License), LGPL (GNU Lesser General Public License), etc.

 Customers can duplicate, distribute and modify the source code of the software under license of GPL and/or LGPL. For details concerning licensing and source code of open source software, click "Click here for OSS information" on "Support" page of the setup menu of this product and read the displayed content.

• Please note that we shall not respond to any inquiries regarding the contents of the source code.

Copyright

Except for open source software licensed under GPL/LGPL and so on, distributing, copying, disassembling, reverse compiling and reverse engineering of the software provided with this product are all expressly prohibited. In addition, exporting any software provided with this product violating export laws is prohibited.

Trademarks and registered trademarks

• Microsoft, Windows, Windows Media, Microsoft Edge, and ActiveX are either registered trademarks or

trademarks of Microsoft Corporation in the United States and/or other countries. Intel and Intel Core are trademarks of Intel Corporation or its subsidiaries in the U.S. and/or other countries.

 Adobe, Acrobat, and Reader are either registered trademarks or trademarks of Adobe in the United States and/or other countries.

• microSDXC Logo is a trademark of SD-3C, LLC.

• iPad and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries.

Android and Google Chrome are trademark of Google LLC.

• Firefox is a trademark of the Mozilla Foundation in the US and other countries.

• The word "QR Code" is a registered trademark of DENSO WAVE INCORPORATED in Japan and other countries. • All other trademarks identified herein are the property of their respective owners.

Precautions for installation

Panasonic i-PRO Sensing Solutions Co., Ltd. assumes no responsibility for injuries or property damage resulting from failures arising out of improper installation or operation inconsistent with this documentatior

■ In order to prevent injury, the product must be securely mounted to a ceiling or wall according to Installation Guide.

■ Installation area for this product

Select an appropriate place for the installation area (such as a strong wall or ceiling) in your particular environment. • Make sure that the installation area is strong enough to hold this product, such as a concrete ceiling.

• Install the camera in the foundation area of the architecture or where sufficient strength is assured. • Do not mount the product on a plaster board or a wooden section because they are too weak. If the product is

unavoidably mounted on such a section, the section shall be sufficiently reinforced.

This camera is designed to be used indoors

This product is not operable outdoors. Do not expose this camera to direct sunlight for hours and do not install the product near a heater or an air conditioner. Otherwise, it may cause deformation, discoloration and malfunction. Keep this camera away from water and moisture.

Do not place this product in the following places

• Locations where a chemical agent is used such as a swimming pool

Locations subject to moisture or oil smoke such as a kitchen

Locations that have a specific environment that is subject to an inflammable atmosphere or solvents

• Locations where a radiation, an X-ray, a strong radio wave or a strong magnetic field is generated

. Locations near coasts directly subjected to sea breezes, or locations subject to corrosive gases such as from hot springs, volcanic regions, etc.

· Locations where the temperature is not within the specified range

- Locations subject to vibrations, such as on vehicles, marine vessels, or above product lines (This product is not designed for on-vehicle use.)
- Locations where it may get directly wet from rain or water splash (including under the eaves, etc.)
- Locations subject to moisture or dust

• Locations subject to sudden changes in temperature such as near air discharge vents of air conditioners or air circulation inlet doors

• Locations near rubber products (packing, rubber feet, etc.)

Screw tightening

Do not use an impact driver. Use of an impact driver may damage the screws or cause tightening excessively. About reflection of light from outside or IR light

A ghost may appear on the screen depending on the incident angle of external light.

In the case of using the IR light, installation of a camera near a wall may cause reflection of infrared rays resulting in a

part of the screen or the entire screen turning whitish.

Refer to our support website <Control No.: C0109> for image examples and measures to take.

Take notice of humidity

Install this product when the humidity is low. If installation is performed when it is raining or in very humid conditions, the inside may be affected by humidity, causing mist-over inside the lens.

Protection from lightning

When cables are used outdoors, there is a chance that they may be affected by lightning. In such a case, install a lightning arrestor close to the camera, and make the length of the network cable between the camera and lightning arrestor as short as possible to prevent the camera from being affected by lightning.

When noise disturbance may happen

Noise may appear in video or audio near a strong electric field from a TV or radio antenna, motors and transformers, or a strong electric field/magnetic field from a power line (lamp line) of AC100 V or more. Conduct the power

distribution work to keep 1 m {3-15/16 inches} away from them or conduct the electric conduit work using metal pipes. (Be sure to make ground connection of the metal pipes.)

ke sure to remove this product if it will no longer be used

This product has no power switch.

When turning off the power, disconnect the power supply from the 12 V DC power supply or the PoE device.

About the battery

A battery is installed inside the camera. Do not leave the battery exposed in environments of excessive heat as a result of sunlight or fire.

Equipment classification and power source indication label

Refer to the indication label on the bottom side of this unit for the equipment classification, power source, and other

Troubleshooting

information.

the trouble

Before requesting service, refer to "Troubleshooting" of Basic Information and Operating Instructions. Then, confirm

Power source *1:	DC 12 V PoE (IEEE802.3af compliant)
Power consumption *1:	DC 12 V: 480 mA/Approx. 5.8 W PoE DC 48 V: 130 mA/Approx. 6.3 W (Class 2 device)
Operating environment Ambient operating temperature: Ambient operating humidity:	-10 °C to +50 °C {14 °F to 122 °F} (Power on range 0 °C to 50 °C {32 °F to 122 °F}) 10 % to 90 % (no condensation)
	-30 °C to +60 °C {-22 °F to +140 °F} 10 % to 95 % (no condensation)
Monitor output (for adjustment):	VBS: 1.0 V [p-p]/75 Ω, composite, Pin jack An NTSC or PAL signal can be outputted from camera (either press the INITIAL SET button quickly (within 1 second) or use software to select NTSC or PAL signal).
EXT I/O terminals:	ALARM IN1 (Alarm input 1/ Black & white input/ Auto time adjustment input) (x1) ALARM IN2 (Alarm input 2/ ALARM OUT) (x1) ALARM IN3 (Alarm input 3/ AUX OUT) (x1)
Audio input: For microphone input: For line input:	σ 3.5 mm stereo mini jack Recommended applicable microphone: Plug-in power type (Sensitivity of microphone: -48 dB±3 dB (0 dB=1 V/Pa, 1 kHz)) Input impedance: Approx. 2 k Ω (unbalanced) Supply voltage: 2.5 V ±0.5 V Input level: Approx10 dBV
Audio output:	ø3.5 mm stereo mini jack (Audio output is monaural.) Output impedance: Approx. 600 Ω (unbalanced) Output level: –20 dBV
Dimensions:	75 mm (W) × 57 mm (H) × 146 mm (D) {2-15/16 inches} (W) × {2-1/4 inches} (H) × {5-3/4 inches} (D) (excluding lens/ power cord plug)
Mass:	Approx. 370 g {0.82 lbs}
Finish:	PC/ABS resin, i-PRO white

Refer to our support website <Control No.: C0106> for further information about Power source and Power consumption information.

Optional accessories

The latest information → Support website "Accessory Selector" <Control No.: C0501>

Standard accessories

Ÿ

Installation Guide (this document)1 pc.	Warranty card1 pc.
IMPORTANT SAFETY INSTRUCTIONS	Code label *11 pc.
*1 This label may be required for network management.	Use caution not to lose this label.

The following parts are used during installation procedures.

Power cord plug1 pc.	Safety wire1 pc.
Mount base1 pc.	Washer1 pc.
Safety wire lug1 pc.	Spring washer1 pc.

Wire lua fixina screv

(M2.5 × 8 mm {5/16 inches}) ...2 pcs. (of them, 1 for spare)



Basic Information "Mount base"

Other items that are needed (not included)

 Fixing screw 		
Installation method	Recommended screw *1	Minimum pull-out strength (per 1 pc.) *2
For mounting on ceiling Mount bracket: 260 g {0.57 lbs} Camera: 370 g {0.82 lbs}	M6 x 16 mm ^{*3 *4} {5/8 inches} x 4 pcs.	562 N {126 lbf} *5
	M4 x 16 mm * ³ {5/8 inches} x 1 pc.	24.5 N {5.5 lbf}
For mounting on wall Mount bracket: 420 g {0.93 lbs} Camera: 370 g {0.82 lbs}	M6 x 16 mm *3 *4 {5/8 inches} x 4 pcs.	724 N {163 lbf} *5
	M4 x 16 mm *³ {5/8 inches} x 1 pc.	24.5 N {5.5 lbf}


*1 Select screws according to the material of the location that the camera will be mounted to. In this

- case, wood screws and nails should not be used.
- *2 This value indicates the minimum pull-out strength required value per screw. For information
- about the minimum pull-out strength, refer to our support website <Control No.: C0120>. era on a robust o
- thickness of 20 mm {25/32 inches} or more.
- *4 The number of required screws or anchor bolts varies depending on the specific cations of the mount bracket (locally procured). Refer to the operating instructions of the mount bracket (locally procured) for information about how to mount the mount bracket.
- *5 Make sure that the screws or anchor bolts separately procured when locally procuring a mount bracket for the ceiling or wall are capable of supporting the total weight (including the moment when mounting to a wall).
- Ethernet cable with RJ45 plug (category 5e or better, straight, 4 pairs (8 pins))
- As necessary, audio input cable, audio output cable, alarm I/O cables, power supply cable
- Tools Compatible lens

Support website "Compatible lens" <Control No.: C0102>





* When using a lens made by other companies, use a lens that has a protruded portion from the mount face of ø20 mm {25/32 inches} or less and a protruded portion from the flange face of 4.5 mm {3/16 inches} or less. Lenses without a focus adjustment mechanism and zoom lenses cannot be used.





Juni Dase 1 pc.	vvasileii pu
fety wire lug1 pc.	Spring washer1 po

Parts and functions











Support website "IP Setting Software" <Control No.: C0123> or "i-PRO Configuration Tool (iCT)" <Control No.: C0133> "Extra optical zoom" <Control No.: C0124> "How to take a wide depth of field" <Control No.: C0127>