


WBL Indoor/Outdoor Wall Mounting Bracket



Features


- Die Cast Aluminum with Surface Spray Treatment
- Cable Entry
- Rubber Cushion Ensures Camera Stabilization
- Pan Tilt Adjustment

Dimensions



Installation

1. Choose the appropriate wall to mount the bracket.




4. Fix the camera onto the baseplate.




NOTE: The actual bracket may vary from the picture above.

2. Complete the bracket installation and wiring.



A: Vertical adjustment screw B: Horizontal adjustment screw

Fix the camera and baseplate onto the bracket; adjust the view and angle.



	WBL
Color	Hikvision white
Feature	Suitable for box or bullet camera and
	housings indoor/outdoor wall mounting
Material	Aluminum alloy
Angle	Horizontal: 360°; Vertical: -45° to 45°
Dimension	83 mm × 123.9 mm × 304 mm
Weight	765 g

NOTES: Pay attention to the color matching.

Install mount on flat surface of wall.

Hole site diameter is within 6.5 mm.

Distance between the two screw holes is 2 mm to 54 mm.

Wall must be capable of supporting more than three times the total load of the camera and the mount.


Maximum capacity load of bracket arm is 8.5 kg

Maximum load capacity of the mount is 2.5 kg.


Order Model

WBL

3. Unscrew the vertical adjustment screw and remove the baseplate from the bracket.



6. The bracket can also be used with housings.



Hikvision USA Inc., 908 Canada Court, City of Industry, CA 91748, USA • Hikvision Canada, 4485 Dobrin, St-Laurent, Quebec, Canada, H4R 2L8 Tel: +1-909-895-0400 • Toll Free in USA: +1-866-200-6690 • E-Mail: sales.usa@hikvision.com • www.hikvision.com © 2015 Hikvision USA Inc. • All Rights Reserved • Specifications subject to change without notice.