





▲ See Product Manual for complete installation and programming instructions.

1.0 Out-of-Box

1.1 Verify that you have received all of the parts listed

| | |
|---|---------------|
|  X 1 | PA-250 |
|  X 1 | Y Power Cord |

| | |
|--|---|
|  X 3 | Terminal Strip 4 Pin Right Angle Removable |
|  X 2 | Terminal Strip 5 Pin Right Angle Removable |


1.2 Download the product manual

Scan the QR code to open and download the product manual

- OR -

1. Go to www.vikingelectronics.com and enter **PA-250** in the search box
2. Under Documents click **Product Manual** to open and download the PDF

2.0 Features Overview



MIC: Microphone Input volume control and LED showing audio input level

ALC: Automatic Level Control adjustment for MIC and PAGE inputs

PAGE: Paging Input volume control and LED showing both activity and audio level

AUX: Auxiliary Input volume control and LED showing both activity and audio level

RING: Volume control and LED indicator for Chime and Loud Ringing tones

MUSIC: Volume control for Background Music Input


BASS: Low frequency tone control

TREBLE: High frequency tone control

MASTER VOLUME: Master volume control and LED level indicator for setting Peak Limiting

POWER: LED indicating power is on (winks off to indicate an overload condition)

3.0 Connections



*See the Product Manual for complete installation and programming instructions.
Questions? Call Viking Product Support: 715-386-8666*

Due to the dynamic nature of the product design, the information contained in this document is subject to change without notice. Viking Electronics, and its affiliates and/or subsidiaries assume no responsibility for errors and omissions contained in this information. Revisions of this document or new editions of it may be issued to incorporate such changes.