







Yealink

QUICK START


DECT Wireless Headset-WH64 Workstation



V1.0




<https://support.yealink.com>



Touch Screen
- Touchscreen
- Écran tactile
- Pantalla tàtil

Speaker
- Lautsprecher
- Haut-parleur
- Altavoz

Microphone
- Mikrofon
- Microphone
- Micrófono




430104003124


1	Busylight (Optional) - Busylight (Optional) - Busylight (Optionnel) - Busylight (Opcional)
2	AUX Port for Third-Party Phone: Used With Telephone Cable/EHS62 (Optional) - AUX-Anschluss für Drittanbieter-Telefon: Verwendung mit Telefonkabel/EHS62 (optional) - Port AUX pour téléphone tiers : utilisé avec un câble téléphonique/EHS62 (en option) - Puerto AUX para teléfono de terceros: usado con cable telefónico/EHS62 (opcional) ⚡ Check/Überprüfen/Vérifier/Verificar: https://support.yealink.com/en/portal/compatible
3	Type-C Port for Yealink Phone - Type-C-Anschluss für Yealink-Telefon - Port Type-C pour téléphone Yealink - Puerto Type-C para teléfono Yealink
4	DC Port (Power) - DC-Anschluss (Strom) - Port DC (Alimentation) - Port DC (Energía)
5	Type-C Port for PC - Type-C-Anschluss für PC - Port Type-C pour PC - Puerto Type-C para PC
6	USB Hub (2*SUB-A, 1*USB-C) - USB-Hub (2*USB-A, 1*USB-C) - Hub USB (2*USB-A, 1*USB-C) - Concentrador USB (2*USB-A, 1*USB-C)



①



②




Hold 3S/- 3 Sekunden halten
 /- Tenir 3 secondes /- Mantener 3 segundos

DECT&Bluetooth Reconnect
 - DECT & Bluetooth Wiederverbinden
 - Reconnexion DECT & Bluetooth
 - Reconexión DECT y Bluetooth



Change to UC platform.
 - Wechsel zur UC-Plattform./ - Changer pour la plateforme UC./ - Cambiar a la plataforma UC.



OR
 - ODER
 - OU
 - O



<https://www.yealink.com/product/yuc>

